WHITESDRYWEAR.COM

How to install a MOLLE Pocket on a MOLLE Plate

NOTE: If a MOLLE Pocket is being installed on a FUSION series drysuit, you will need a FUSION Pocket Support System Kit (#1FPSUPSYS-KIT). This prevents the drysuit from pulling down when pockets are loaded with gear.

INSTALLATION

1. On the backside of the pocket, take the webbing straps and alternate weaving through the MOLLE Plate slots and webbing on the pocket back.
2. Fold the VELCRO™ Brand tabs up and secure with the VELCRO™ Brand booklets.

Your MOLLE Pocket is now ready to use!

1a.



1b.



1c.



1d.



1e.



1f.



2a.



2b.

